

# RCI Technologies


## Water Sensor



Universal Indicator



OEM  
Interface  
Module



Mounting Brackets



**\*HARDWARE INCLUDED**



Sensor

The RCI Water Sensor and Indicator have been designed to operate when the RCI Purifier is in need of purging. A buzzer followed by a red indicator light will come on when the water level in the purifier reaches the sensor level. The buzzer will last 10 seconds. The light will stay on until the unit is purged.

Phone: (800) 868-2088 \* (909) 305-1241 \* Fax: (909) 305-1245

www.rcitechnologies.com \* e-mail: info@rcitechnologies.com